# LCD / LCM SPECIFICATION



WINSTAR Display Co.,Ltd. 華凌光電股份有限公司

# Winstar Display Co., LTD





WEB: <a href="https://www.winstar.com.tw">https://www.winstar.com.tw</a> E-mail: sales@winstar.com.tw

#### **SPECIFICATION**

MODULE NO.: WO12864D2

## **General Specification**

Item	Dimension	Unit
Number of Dots	128 x 64 dots	_
Module dimension	90.0 x 52.8 x 6.6	mm
View area	70.7 x 38.8	mm
Active area	66.52 x 33.24	mm
Dot size	0.48 x0.48	mm
Dot pitch	0.52 x 0.52	mm
Duty	1/64 , 1/9 Bias	
Backlight Type	LED	
IC	ST7565P	
Interface	6800/8080/4-Line SPI	

#### **Absolute Maximum Ratings**

Item	Symbol	Min	Тур	Max	Unit
Operating Temperature	Тор	-20	_	+70	$^{\circ}$
Storage Temperature	T <sub>ST</sub>	-30	_	+80	$^{\circ}$
Power Supply Voltage	VDD	-0.3	_	3.6	V
Power supply voltage (VDD standard)	V0, VOUT	-0.3	_	14.5	V
Power supply voltage (VDD standard)	V1, V2, V3, V4	-0.3	- (	V0+0.3	v

## **Electrical Characteristics**

Item	Symbol	Condition	Min	Тур	Max	Unit
Supply Voltage For Logic	V <sub>DD</sub> -V <sub>SS</sub>		2.7	3.0	3.3	V
	Ċ	Ta=-20°C	10.0	10.2	10.4	V
Supply Voltage For LCM	V <sub>0</sub> -V <sub>SS</sub>	Ta=25°C	9.8	10.0	10.2	V
A		Ta=70°C	9.6	9.8	10.0	V
Input High Volt.	V <sub>IH</sub>	_	$0.8~\mathrm{V_{DD}}$	_	$V_{ m DD}$	V
Input Low Volt.	$V_{\rm IL}$	_	Vss	_	0.2 V <sub>DD</sub>	V
Output High Volt.	V <sub>OH</sub>	_	$0.8~\mathrm{V_{DD}}$	_	$V_{\mathrm{DD}}$	V
Output Low Volt.	V <sub>OL</sub>	_	Vss	_	$0.2V_{DD}$	V
Supply Current (LED backlight is not included)	$I_{DD}$	V <sub>DD</sub> =3.0V		0.6	1	mA

#### **Interface Pin Function**

Pin No.	Symbol	Level	Description		
1	1 /CS1		This is the chip select signal. When /CS1 = "L", then the		
1	/CS1		chip select becomes active, and data/command I/O is enabled.		
2	/RES		When /RES is set to "L", the settings are initialized.		
			This is connect to the least significant bit of the normal MPU		
			address bus, and it determines whether the data bits are data or		
3	A0		a command.		
			A0 = "H": Indicates that D0 to D7 are display data.		
			A0 = "L": Indicates that D0 to D7 are control data.		
			When connected to an 8080 MPU, this is active LOW.		
			(R/W) This terminal connects to the 8080 MPU /WR signal.		
			The signals on the data bus are latched at the rising edge of the		
4	/WR(R/W)		/WR signal.		
'	/ WIK(IV W)		When connected to a 6800 Series MPU:		
			This is the read/write control signal input terminal.		
			When $R/W = "H"$ : Read.		
			When R/W = "L": Write.		
			When connected to an 8080 MPU, this is active LOW.		
		/RD(E)	(E) This pin is connected to the /RD signal of the 8080 MPU,		
5	5 /DD(E)		and the ST7565P series data bus is in an output status when		
	/RD(L)		this signal is "L".		
	,		When connected to a 6800 Series MPU, this is active HIGH.		
			This is the 6800 Series MPU enable clock input terminal.		
6	DB0	- P			
7	DB1	T.			
8	DB2				
9	DB3		This is an 8-bit bi-directional data bus that connects to an 8-bit		
10	DB4		or 16-bit standard MPU data Bus.		
11	DB5		-Dus.		
12	DB6				
13	DB7				
14	VDD		Shared with the MPU power supply terminal VDD. (3.3 V)		
15	VSS		This is a 0V terminal connected to the system GND.		
16	VOUT		DC/DC voltage converter. Connect a capacitor between this		
10	1001	VOU1		terminal and VSS.	

第4頁,共7頁

17	CAP5+		DC/DC voltage converter. Connect a capacitor between this		
			terminal and the CAP1- terminal.		
18 CAP3	CAP3+		DC/DC voltage converter. Connect a capacitor between this		
			terminal and the CAP1- terminal.		
19 CA	CAP1-		DC/DC voltage converter. Connect a capacitor between this		
17	C/ H 1		terminal and the CAP1+ terminal.		
20	CAP1+		DC/DC voltage converter. Connect a capacitor between this		
20	C/H 1		terminal and the CAP1- terminal.		
21	CAP2+		DC/DC voltage converter. Connect a capacitor between this		
21			terminal and the CAP2- terminal.		
22	CAP2-		DC/DC voltage converter. Connect a capacitor between this		
	CAP2-	CAF2-	terminal and the CAP2+ terminal.		
23	CAP4+		DC/DC voltage converter. Connect a capacitor between this		
23	CAI 4		terminal and the CAP2- terminal.		
24	VRS		This is the externally-input VREG power supply for the LCD		
24	VIXS		power supply voltage regulator.		
25	V4		This is a multi-level power supply for the liquid crystal drive.		
26	V3		The voltage Supply applied is determined by the liquid crystal		
			cell, and is changed through the use of a resistive voltage		
27	V2		divided or through changing the impedance using an op. amp.		
			Voltage levels are determined based on Vss, and must		
28	V1		maintain the relative magnitudes shown below.		
			$V0 \ge V1 \ge V2 \ge V3 \ge V4 \ge Vss$		
			When the power supply turns ON, the internal power supply		
			circuits produce the V1 to V4 voltages shown below. The		
29	V0		voltage settings are selected using the LCD bias set command.		
			1/65 DUTY 1/49 DUTY 1/33 DUTY 1/55 DUTY 1/53 DUTY V1 8/9*V0,6/7*V0 7/8*V0,5/6*V0 5/6*V0,4/5*V0 7/8*V0,5/6*V0 7/8*V0,5/6*V0		
			V1   0/3 V0,07 V0   7/8 V0,3/8 V0   3/8 V0,4/3 V0   7/8 V0,3/8 V0   7/8 V0,3/6 V0   7/8 V0,3		
		1	V4 1/9*V0,1/7*V0 1/8*V0,1/6*V0 1/6*V0,1/5*V0 1/8*V0,1/6*V0 1/8*V0,1/6*V0		
			Output voltage regulator terminal. Provides the voltage		
		between VDD and V5 through a resistive voltage divider.			
30	VR		IRS = "L": the V5 voltage regulator internal resistors are not		
	*10		used .		
			IRS = "H": the V5 voltage regulator internal resistors are		
,			used .		
			This is the MPU interface switch terminal.		
31	C86		C86 = "H": 6800 Series MPU interface.		
			C86 = "L": 8080 MPU interface.		

		This is the parallel data input/serial data input switch terminal.
		P/S = "H": Parallel data input.
		P/S = "L": Serial data input.
		The following applies depending on the P/S status:
32	P/S	P/S Data/Command Data Read/Write Serial Clock
32	173	'H' A0 D0 to D7 RD, WR X
		"L" A0 SI (D7) Write only SCL (D6)
		When P/S = "L", D0 to D5 may be "H", "L" or Open. RD (E) and WR (R/W) are fixed to either "H" or "L".
		With serial data input, It is impossible read data from RAM.
	/НРМ	This is the power control terminal for the power supply circuit
22		for liquid crystal drive.
33		HPM = "H": Normal mode
		HPM = "L": High power mode
34	IRS	This terminal selects the resistors for the V5 voltage level
		adjustment.
		IRS = "H": Use the internal resistors
		IRS = "L": Do not use the internal resistors. The V5 voltage
		level is regulated by an external resistive voltage divider
	_	attached to the VR terminal

#### **Contour Drawing**

